


# XDJ-R1

## Hardware Diagram for rekordbox dj



GROUP	No.	NAME	FUNCTION	(+ SHIFT)
<b>DECK</b>				
	1	▶/II (PLAY/PAUSE)	Play/Pause	
	2	CUE	Set Cue/Play, Back Cue	Jump to track start
	3	JOG	Top of jog Scratch (Vinyl on), Pitch Bend (Vinyl off) Side of jog Pitch Bend	Seek
	4	SHIFT	Shift	-
	5	TRACK SEARCH	PREV / NEXT TRACK	
	6	AUTO BEAT LOOP	Loop Size Select Autp Loop On/Off	Loop Move Reloop/Exit
	7	MODE(HOT CUE/SAMPLER)	-	
	8	CALL	-	
	9	A	Hot Cue Point 1	Delete Hot Cue Point 1
	10	B	Hot Cue Point 2	Delete Hot Cue Point 2
	11	C	Hot Cue Point 3	Delete Hot Cue Point 3
	12	A	Hot Cue Point 1	Delete Hot Cue Point 1
	13	B	Hot Cue Point 2	Delete Hot Cue Point 2
	14	C	Hot Cue Point 3	Delete Hot Cue Point 3
	15	MASTER	Master	
	16	SYNC	Sync On/Off	
	17	TEMPO	Tempo Control	
	18	MASTER TEMPO	Master Tempo On/Off	
	19	TEMPO RANGE	Tempo Range	
	20	VINYL MODE	Vinyl Mode On/Off	
	21	BEAT	FX beat select	-
	22	BEAT FX (TRANS)	TRANS On/Off	
	23	BEAT FX (FLANGER)	FLANGER On/Off	
	24	BEAT FX (ECHO)	ECHO On/Off	
	25	BEAT FX (ROLL)	ROLL On/Off	
	26	LEVEL/DEPTH	FX Level Adjust	
	27	TAP	FX TAP (Adjust tempo manually)	Switch FX MODE (Single/Multi)
<b>BROWSE</b>				
	28	TIME	Deck Change	QUANTIZE
	29	BACK	Close folder/ Scroll layer	Show Tag List/ Playlist Palette
	30	SELECT PUSH	rotate Browse(files/folders/items) push Load Track	Waveform Zoom In/Out Add/delete Tag List

GROUP	No.	NAME	FUNCTION	(+ SHIFT)
<b>MIXER</b>				
	31	TRIM	GAIN	-
	32	HI	EQ (HI)	-
	33	MID	EQ (MID)	-
	34	LOW	EQ (LOW)	-
	35	COLOR	SOUND COLOR FX Parameter adjust	-
	36	SOUND COLOR FX	NOISE	SOUND COLOR FX (NOISE) On/Off
			CRASH	SOUND COLOR FX (CRUSH) On/Off
			PITCH	SOUND COLOR FX (PITCH) On/Off
			FILTER	SOUND COLOR FX (FILTER) On/Off
	37	Channel fader	Channel fader	-
	38	Crossfader	Crossfader	-
	39	CROSS F. CURVE	Crossfader curve	-
	40	CUE	Headphone CUE On/Off	-
	41	DECK, PHONE/LINE Switch	Input Switch	-
	42	HEADPHONES MIXING	Headphone monitor balance	-
	43	HEADPHONES LEVEL	Headphone volume adjustment	-
	44	MASTER LEVEL	Master Volume adjustment	-
	45	BOOTH MONITOR	Booth monitor adjustment	-
	46	AUX LEVEL	AUX Volume adjustment	-
	47	AUX(ON/OFF)	AUX On/Off	-
	48	MIC LEVEL	MIC Volume adjustment	-
	49	MIC EQ	MIC Equalizer	-
	50	MIC (ON/OFF)	MIC On/Off	-

The functions of the hardware of XDJ-R1.